



The Most Reliable Panic Button Card for K-12 Schools



Rescue Card Helps Schools Stay Safe and Connected During Emergencies

The Rescue Card offers multiple reporting modes: test mode, Level 1, and Level 2. **Level 1** notifies internal responders, while **Level 2** sends alerts to all staff, activates Repeater strobe lights, and triggers 911+ Concierge for reliable police response.



Repeaters for Precise Location Awareness

Repeaters are strategically placed in every classroom to ensure accurate indoor location tracking and reliable coverage.



Room-Level Accuracy



Signal Repeating for Coverage



Optional Strobe Attachment

Audible & Visual Alert Station

Each school is provided with an Alert Station that receives emergency signals from the cards and repeaters. This station is equipped with cellular capabilities for dependable emergency reporting.



Audible & Visual Alerts




Backed with Cellular



Button to Test and Silence



learn more at punchrescue.com



Feature Rich Panic Button

- Simple Panic Button
- Lightweight Card Design
- Worn Around Neck or Belt
- Easy Testing Mechanism
- Emergency App Integration
- 2 Levels of Reporting
- Track Card Online Status
- Room-Level Accuracy
- Doesn't Rely on Wifi
- Outdoor Use